



CCTL1C Tree Light placed 25' above grade for best results.

Black sun resistant cable ties located 3-5 feet on center. 3M #054007-06275. Use #10 stainless steel screw.

#10 Stainless steel screw.

#16-2 No-Ox wire.

3/4" poly pipe sleeve to 8" above grade. Use 3M cable tie and #10 stainless steel screw to secure to tree surface.

Poly pipe prevents damage to wire from maintenance equipment.

Bury wire a minimum of 6" deep.

Drawing not to scale

MODEL #	Tree Light Mounting Detail
	NOTES: • Use stainless steel Hanger Bolt and Nut Kit order number CTREEH1 to fasten Tree Light to trunk of tree.
Rev. 8-16-03	